




READ INSTRUCTIONS - Failure to assemble cover properly will void warranty.




TruXedo® Deuce is a registered United States trademark of TruXedo. Patents pending.














— 5 —











DEUCE REPLACEMENT PARTS TRUXEDO®

1	*	Deuce [®] Replacement Cover	17	1704860
2	*	Cross Bow Tubes Assembled	18	1704864
3	*	Safety Strap	19	1117467
4	1704715	Extruded Reatainer Loop	20	1115354
5	*	Black Front Header	21	1704658
6	1117594	Header Guide Retainer Assy	22	1704660
7	1704707	Header Guide_2011	23	1704213
8	1704879	Lever Lock Assy.	24	1114773
9	1704194	Weld Nut, Tab, 5/16"	25	1702926
10	1117781	Header End Plug_Front_LH & RH	26	*
11	*	Side Rail, Passenger Side	27	*
12	*	Header Seal_Tailgate	28	1704614
13	*	Header Seal, Cab	20	*
14	1117741	Outside Linkage Tie-Bar		*
15	*	Tie-Bar Center Linakge	30	1704054
16	1117766	Linkage Pins_Includes Washers	31	1704654

1704860 1704864 1117467 1115354 1704658 1704660 1704213	Release Levers Header Stop & Striker Pin Assy Rear Header 08 End Plugs (Set of 2) Header Insert Safety Clip Tension Control Housing & Spring Tension Header Stop_Deuce Latch Assembled
1702926	Screw Hex HD 5/16"x 7/8"
*	Aluminum Clamp Assy
	Side Rail, Driver's Side
1704614	Side Rail Front, Driver's Side
*	Rail Underbody Assembly, Driver's Side
*	Rail Underbody Assembly, Pass Side
1704654	Hinge Assembly

32	1704709	Wasł
33	1117767	Side
34	*	Hook
35	1704615	Side
36	*	Black

sher Plastic 5/16 dia x 1.25 RD e Rail End Plugs_Front & Back ok and Loop Fasteners e Rail Front, Pass. Side ck Rear Header

TROUBLE SHOOTING

FRONT LATCH WON'T RELEASE EITHER SIDE:

-Adjust tie-bar connector ends outward to eliminate slack in entire linkage mechansim. See Step 7.

FRONT RELEASE LEVERS, LINKAGE AND STRIKER PINS SEEM TO BIND:

-Lubricate all linkage pivot points with mineral oil. Lubricate striker pins and pivot base with a graphite dry liquid lubricant.

FRONT OF COVER WILL NOT STAY LATCHED DOWN:

-Make sure striker pins are returning to closed 90 degree position. See Step 13. Lubricate striker pins and pivot base with a graphite dry lubricant.

TAILGATE HEADER WILL NOT LATCH:

-Check side rails to make sure they are level, see Step 3 and 3-A. Position clamps higher

or lower to achieve level side rails

FABRIC COVER IS TOO TIGHT OR TOO LOOSE:

Adjust rear tension controls, See step 10.

LIFETIME WARRANTY

TruXedo. warrants that all new, unused products are free from defects in material and workmanship. This Warranty is effective if the product is properly installed and used for the purpose intended for the life of the product. It applies to the original buyer only. TruXedo.'s obligation under this Warranty is limited to repairing, or at its option, replacing any part that is returned, transportation prepaid, to TruXedo., Yankton, South Dakota, if the product is, in our judgment, defective. All materials must be accompanied by an RMA (Returned Material Authorization) number requested and authorized in advance of returning the materials. TruXedo. shall not be liable or responsible to supply or pay labor to replace any part found defective, nor shall it be liable for any damages of any kind or nature to person, product, or property.

There are no Warranties for used products or products that have been repaired, altered, modified, subjected to misuse, negligence, accident or ordinary wear and tear. Call 1-877-878-9336 for complete details.

TruXedo. products are sold without any express warranty except as set forth above. TruXedo. is not obligated to honor warranty claims if Genuine TruXedo. parts are not utilized.

DIRECT ALL WARRANTY CLAIMS TO TRUXEDO. AT 1-877-878-9336

SAFETY INSTRUCTIONS

- 1. Do not place objects on or against cover or framework.
- 2. Do not tie cargo to TruXedo[®] Deuce framework.
- 3. <u>Never</u> allow children or pets to occupy pickup box while cover is closed.
- 4. Cover is not airtight. Special care is required to keep cargo clean and dry.
- 5. Fabric cover won't prevent theft of contents inside truck box.
- 6. Cover must be rolled fully open and secured with safety straps when towing vehicle backwards.
- 7. Never drive vehicle while hinged front of cover is open.

WARNING

'!'

Tighten clamps securely on side rails before driving vehicle, to prevent cover from blowing off.

OWNER/USER RESPONSIBILITIES

It is the responsibility of the owner/user to read this manual and comply with the operating procedures. The owner/user is also responsible for inspecting their TruXedo[®] Deuce cover, and for having parts repaired or replaced when worn or damaged.

Failure to follow safety instructions and warning labels could result in failure of your cover system and/or personal injury.

MESSAGES TO INSTALLER

• Always wear safety glasses and/or other necessary protective equipment when installing your TruXedo[®] Deuce.

• These instructions are complete for most pickup models. Additional instructions are included, if required for your pickup. Please read entire manual before installing your Truxedo[®] Deuce.

COVER MAINTENANCE

Vinyl cover can be hand washed with mild soap and water or cleaned in a car wash. Thoroughly rinse cover to remove any soap residue. Cover can be treated with any vinyl protectant made for tonneau covers.

Never use silicon, petroleum, or citrus based products on your tonneau cover.

Questions? Call our friendly customer service staff at Truxedo Toll Free: 1-877-878-9336								
Register online at www.truxedo.com or mail this form to: TruXedo, P.O. Box 1078, Yankton, SD 57078-0713 Name:								
Address:								
City:	State:	Zip:						
Phone Number:	Phone Number:							
Email Address:	Email Address:							
Date Purchased:Price Paid:								
Dealer Name:								
Pickup Make:								
Model:Year:								
Product Purchased:	□ TruXedo Lo Pro QT □ TruXedo Deuce	□ TruXedoPlus □						